





Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Piese de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli



XX = AA, AD, ...

- 1 - B 961706 XX
- 2 - A 961157 XX
- 3 - A 861080 XX
- 4 - B 961645 NU
- 5 - A 861397 NU
- 6 - B 960889 NU
- 7 - B 960654 NU
- 8 - B 960712 XX
- 9 - B 964702 NU

- 10 - A 962991 XX
- B 960853 XX
- 10a - E 1482 XX
- 10b - B 961705 XX
- 11 - B 960221 NU
- 12 - B 960900 XX
- 12a - B 962046 NU - B...XG
- 13 - B 960845 NU
- 14 - A 960019 XX
- 15 - B 961922 XX



B D136 XX




CERALINE




Ideal Standard


01.2026 / B565107




B C197 ..




B C268 ..



B C822 ..



B C193 ..
B C203 ..



B C192 ..



Ideal Standard International NV
Corporate Village – Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
www.idealstandard.com

